



PX2 INSTALL ADVERTISING FILE

1. Save the file you would like to transfer to the PX2 Advertising folder onto a USB drive. Ensure the file is formatted as follows
 - a. Size-1024 x 768
 - b. JPG format.
2. Turn machine on.
3. Once the Green alignment screen is displayed touch the ProBatter Bullseye in the upper left hand corner.
4. Type into the keypad 9876
5. Touch the check button
6. Touch the End Program button.
7. Insert the USB drive
8. Once the Windows desktop screen is displayed double click the My Computer icon.
9. Locate the USB drive and the file you would like to upload.
10. Right click on the file and copy.
11. Close all windows.
12. Double click the My Computer icon
13. Double click the C drive
14. Double click the Program Files folder
15. Double click file labeled either Pitch or Pitch 8.0
 - a. If your machine has both folders use Pitch 8.0
16. Double click AdvertVideos folder
17. Right click in folder and paste file to folder.
18. Close all windows.
19. Shut down computer.
20. Remove USB drive
21. Restart computer.